
NAME. SOLUTION

PROBLEM 1: At a point in a loaded member, the stresses relative to a x-y-z coordinate system are given by:

$$\begin{bmatrix} \sigma \end{bmatrix}_{\text{aye}} = \begin{bmatrix} -15 & 0 & -25 \\ 0 & 10 & -20 \\ -25 & -20 & 0 \end{bmatrix} MPa$$

1a. Draw the state of stress on the cube shown and determine the principal stresses for this state of stress and their directions cosines. (If you use MATLAB or Excel to perform calculations, be sure to print out the Command Window or spreadsheet that contains the commands you used to perform the calculations.)



>> Sigma=[-15 0 -25; 0 10 -20; -25 -20 0]

Sigma =

ORIGINAL STATE OF STRESS IN MPa

>> [EV,PS]=eig(Sigma)

EV =

PS =

1b. What angles (in degrees) do each of the principal stresses make with the x, y, and z axes?

$$\sigma_1$$
: θ_{1x} = 136.3 θ_{1y} = 105.7 θ_{1z} = 129.5

$$\sigma_2$$
: θ_{2x} = 125.8 θ_{2y} = 43.3 θ_{2z} = 69.1

$$\sigma_{3}$$
: θ_{3x} = 111.5 θ_{3y} = 129.0 θ_{3z} = 46.8

>> acos(EV)*180/pi

ans =

	1	Z	3
x	136.3170	125.8414	111.4864
У	105.6995	43.2698	129.0325
2	129.4536	69.1260	46.7636

Checking the dot product between direction cosine vectors

ans =

-1.1102e-016

>> dot(EV(:,1),EV(:,3))

ans =

-2.7756e-016

>> dot(EV(:,2),EV(:,3))

ans =

1.9429e-016

ALL THREE DOT PRODUCTS


ARE ESSENTIALLY ZERO,

MEANING THAT THE

THREE PRINCIPAL

AXES ARE ORTHOGONAL.

1c. Determine the transformation matrix from the original state of stress to the principal state of stress and prove that it is the transformation matrix by using it to transform the original state of stress to the principal state. Illustrate the stress cube the represents the principal state of stress.



```
>> T=EV'
```

T =

-0.7232 -0.2706 -0.6355

-0.5855 0.7281 0.3563

-0.3663 -0.6298 0.6850

>> SigPrincipal=T*Sigma*T'

SigPrincipal =


-36.9676 -0.0000 -0.0000

-0.0000 0.2130 0.0000

-0.0000 0.0000 31.7546

THE MP

1c. What is the absolute maximum shear stress and the normal stresses that accompany it? Illustrate the stress cube in this state.



>> T2=[.7071 0 -.7071; 0 1 0; .7071 0 .7071]

T2 =

0.7071 0 -0.7071

0 1.0000 0

0.7071 0 0.7071

>> T3=T2*T

T3 =

-0.2524 0.2540 -0.9337

-0.5855 0.7281 0.3563

-0.7704 -0.6366 0.0350

>> MaxShear=T3*Sigma*T3'

MaxShear =

-2.6064 -0.0000 -34.3604

-0.0000 0.2130 0.0000

-34.3604 0 -2.6064

IN MPa

(4a)

1d. What angles does the absolute shear stress make with the x, y, and z coordinates

$$\tau_{max}$$
: $\theta_x = 104.G$ $\theta_y = 75.3$

$$\theta_{v} = 75.3$$

$$\theta_{z}$$
= 159.0

>> acos(T3)*180/pi

ans =

104.6171 75.2875 159.0191

125.8414 43.2698 69.1260

140.3855 129.5418 87.9918

1e. Determine the stress invariants for the states of stress for the original stress state, the principal stress state, and the state of stress that contains the maximum shear stress. What is the relationship between the invariants in these three states of stress?

THE INVARIANTS FOR THE THREE STRESS STATES ARE THE SAME (INVARIANT)

$$I_3 = 250 \text{ mPa}^3$$

```
>> poly(Sigma)

ans =

1.0e+003 *

0.0010  0.0050 -1.1750  0.2500

>> poly(SigPrincipal)

ans =

1.0e+003 *

0.0010  0.0050 -1.1750  0.2500


>> poly(MaxShear)


ans =


1.0e+003 *

0.0010  0.0050 -1.1750  0.2500
```

PROBLEM 2: The circular beam shown in the figure below is fixed into the wall at A and has a force $\vec{F} = 1000N \cdot \hat{i} + 2000N \cdot \hat{j} + 1000N \cdot \hat{k}$ and moment $\vec{T} = 5000N \cdot m \cdot \hat{i}$ applied to the end at B.







2a. Using the bottom figure on Page 5, complete the free body diagram of the circular beam. Using the top figure on page 6 illustrate the resultant internal forces and moments in the beam at the wall.

$$\Sigma F_x = 0 = A_x + 1000N \Rightarrow A_x = 1000N$$

$$\Sigma F_{y} = 0 = A_{y} + 2000N$$
 $\Rightarrow A_{y} = -2000N$

2b. Using the lower diagram on Page 6 illustrate the natural axis, include the angle it makes with respect to the y or z axes, and identify the location where the normal stress will be maximum.

RESOLTANT FORCE IN Y-2 PLANE
$$F_R = \sqrt{(1000N)^2 + (2000N)^2} = \frac{2236N}{2236N}$$

$$\widehat{C}_{RF} = \frac{2000N}{2236N} J + \frac{1000N}{2236N} \widehat{A} = \frac{0.8944 \widehat{J} + 0.4472 \widehat{J}_{A}}{2236N}$$

$$\widehat{F}_R = 2236N (0.8944 \widehat{J} + 0.4472 \widehat{A}$$

RESCLIANT MOMENT IN THE Y-Z PLANE $M_R = \sqrt{(-500 \text{ N·m})^2 + (1000 \text{ N·m})^2} = 1118 \text{ N·m}$ $\hat{C}_{\text{Rm}} = -\frac{500 \text{ N·m}}{1118 \text{ N·m}} \hat{S} + \frac{1000 \text{ N·m}}{1118 \text{ N·m}} \hat{R} = 0.4472 \hat{J} + 0.8944 \hat{R}$

MR = 1118N·m (-0.4472) + 0.8944 h)

LOCATION OF THE NETURAL AXES

$$\nabla_{x} = 0 = \frac{1000N}{91(\frac{0.075m}{2})^{2}} - \frac{(1118N \cdot m) \cdot r}{91(0.1075m)^{4}}$$

$$\Gamma = \frac{1000N}{(0.075m)^{2}} \cdot \frac{(0.075m)^{4}}{64 \cdot (1118N \cdot m)} = 0.0003145m$$


ANGLE NETURAL AXIS MAKES WITH $\frac{7}{2}$ AXIS $\Theta_{\xi} = \cos^{-1} 0.8944 = \frac{26.57^{\circ}}{2}$

2c. Draw the complete stress cube for the location of the maximum normal stress on this surface.


Normal Stress AT A_T $T_{x} = \frac{1000N}{91(0.075m)^{2}} + \frac{(1118N \cdot m) \cdot (\frac{6.675m}{2})}{91(0.075m)^{4}}$ $= 226.4 (10^{3}) Pa + 27.00 (10^{6}) Pa = 27.22 (10^{6}) Pa = 27.22 M Pa$

THE SHEAR STRESS AT AT IS ONLY DUE TO THE TORQUE SINCE FR IS PERPENDICULAR TO THE NETWAL AXIS

$$\Sigma_{YZ'} = \frac{-5000 \text{ N·m}}{\frac{917}{32}(0.075\text{m})^4} = \frac{-60.36(10^6)Pa}{60.36\text{mPa}} = \frac{-60.36\text{mPa}}{60.36\text{mPa}}$$



2d. Using the state of stress illustrated in the previous part, draw Mohr's circle and determine the principle stresses, maximum shear stress, normal stress corresponding to the maximum shear and the angles these states of stress make with the original states of stress. Draw a stress cube that illustrates both states of stress relative to the original state of stress.




NAME: _____

PROBLEM 1:At a point in a loaded member, the stresses relative to a x-y-z coordinate system are given by:

$$\left[\sigma\right]_{xyz} = \begin{bmatrix} -15 & 0 & -25\\ 0 & 10 & -20\\ -25 & -20 & 0 \end{bmatrix} MPa$$

1a. Draw the state of stress on the cube shown and determine the principal stresses for this state of stress and their directions cosines. (If you use MATLAB or Excel to perform calculations, be sure to print out the Command Window or spreadsheet that contains the commands you used to perform the calculations.)



1b. What angles (in degrees) do each of the principal stresses make with the x, y, and z axes?


 σ_1 : θ_{1x} =

 $\theta_{1y} =$


 $\theta_{1z} =$

 σ_2 : θ_{2x} = θ_{2y} = θ_{2z} =

1c. Determine the transformation matrix from the original state of stress to the principal state of stress and prove that it is the transformation matrix by using it to transform the original state of stress to the principal state. Illustrate the stress cube the represents the principal state of stress.



1c. What is the absolute maximum shear stress and the normal stresses that accompany it? Illustrate the stress cube in this state.



1d. What angles does the absolute shear stress make with the x, y, and z coordinates

 τ_{max} : θ_{x} =


 $\theta_y =$


 $\theta_z =$


1e. Determine the stress invariants for the states of stress for the original stress state, the principal stress state, and the state of stress that contains the maximum shear stress. What is the relationship between the invariants in these three states of stress?


-6-

PROBLEM 2: The circular beam shown in the figure below is fixed into the wall at A and has a force $\vec{F} = 1000N \cdot \hat{i} + 2000N \cdot \hat{j} + 1000N \cdot \hat{k}$ and moment $\vec{T} = 5000N \cdot m \cdot \hat{i}$ applied to the end at B.









2a. Using the bottom figure on Page 7, complete the free body diagram of the circular beam. Using the top figure on page 8 illustrate the resultant internal forces and moments in the beam at the wall.

-9-


2b. Using the lower diagram on Page 8 illustrate the natural axis, include the angle it makes with respect to the y or z axes, and identify the location where the normal stress will be maximum.

-10-

2c. Draw the complete stress cube for the location of the maximum normal stress on this surface.

-11-

2d. Using the state of stress illustrated in the previous part, draw Mohr's circle and determine the principle stresses, maximum shear stress, normal stress corresponding to the maximum shear and the angles these states of stress make with the original states of stress. Draw a stress cube that illustrates both states of stress relative to the original state of stress.



Union College Mechanical Engineering

-13-

Union College Mechanical Engineering

-14-