10

11

12

13

14

15

16

17

10 Turn the top section including the tenon to fit into the pre-bored mortise. Use a set of callipers to measure the boring head and then transfer the measurements to the tenon to be sure of a good fit. If you're unsure, make the callipers slightly oversize and take a small amount off at a time, testing every cut until the fit is perfect. A perfect fit is not a tight fit, remember the glue needs space so if the joint is screeching in and out, take a bit away so the joint goes together with little effort

11 When the two sections of your lamp are assembled you should be able to hide any join with a well-placed 'V' cut or fillet. In this case, I've placed a fillet either side of a bead to disguise the join

12 It's now time to turn the base. Mount this onto a screw chuck to avoid screw holes from a faceplate being visible in the top of the base. The base has a dovetailed recess on the bottom, which we will use to mount it onto a chuck for turning. You will also notice that the underside is slightly fluted to the centre point; this will guide the cable as it comes through the bottom

13 This lamp includes a set of bung feet. Drill a 20mm tenon that you can then glue the feet into

14 After turning the base around into the chuck and roughing it down, size the mortise ready for finishing

15 You need to leave some weight in the base to make a nice stable lamp and you also need to drill an 8mm hole through the base for the flex. Use a 6mm bowl gouge to give a nice finishing cut ready for sanding

16 Test the fit and make sure the design flows nicely. Make any adjustments as necessary and then you're ready for the finishing

17 As before, sand with abrasives starting at 100 grit and working through to 600. Follow this with sanding sealer and paste wax ●

WT_289_32_37_COLWIN_PRO_CW_MBJRcwS.indd 37 06/01/2016 11:26