

Widget Maintenance Manual

Overview

The service proceeds in four stages. Each stage depends on the one before it, so do not skip ahead. Read this section end to end before you pick up a single tool.

Required Parts

- Frame plate, anodized
- Hex bolts, eight of them
 - Washers ship in the bolt bag
- Torque wrench, calibrated this year

Procedure

1. Seat the frame plate flat on the jig.
2. Thread every bolt by hand before torquing any of them.
3. Torque to spec in a star pattern, never in a circle.

Key Points:

A hand-thread that binds means the plate is not seated. Back it out and start the stage again rather than forcing the bolt.



Verification

Verify the assembly cold, before the first run. A warm frame hides the very gap you are looking for.

- a. Check the gap with a feeler gauge at all four corners.
- b. Re-torque after ten minutes of rest.
- c. Record the final reading in the build log.

Troubleshooting

Key Points:

A reading that drifts between the first and second torque pass is a seating problem, not a calibration problem.