

=

WHAT'S NEW? → G-code Explained | List of Most Important G-code Commands (https://howtomechatronics.com/tutorials/g-c...



(https://www.youtube.com/user/DejanNedelkovski)

G+(https://plus.google.com/+Howtomechatronics)

(https://www.facebook.com/howtomechatronics/)

Follow me on: ()

Q

Home (https://howtomechatronics.com)


Tutorials (https://howtomechatronics.com/category/tutorials/) > Arduino Tutorials (https://howtomechatronics.com/category/tutorials/arduino/)

#### **Ultrasonic Sensor HC-SR04 and Arduino Tutorial**

- **Legian** (https://howtomechatronics.com/author/howtom12\_wp/) □ Arduino Tutorials (https://howtomechatronics.com/category/tutorials/arduino/)
- Q 95 (https://howtomechatronics.com/tutorials/arduino/ultrasonic-sensor-hc-sr04/#comments)




In this Arduino Tutorial we will learn how the HC-SR04 Ultrasonic Sensor works and how to use it with the Arduino Board. You can watch the following video or read the written tutorial below.




### **How It Works - Ultrasonic Sensor**

It emits an ultrasound at 40 1000 detains this crosses to the pour bette and the speed of the sp



The HC-SR04 Ultrasonic Module has 4 pins, Ground, VCC, Trig and Echo. The Ground and the VCC pins of the module needs to be connected to the Ground and the 5 volts pins on the Arduino Board respectively and the trig and echo pins to any Digital I/O pin on the Arduino Board.



(https://howtomechatronics.com/wp-

content/uploads/2015/07/Ultrasonic-Sensor-Cirucit-Schematics-04.png)

### Components needed for this tutorial


You can get these components from any of the sites below:

- Ultrasonic Sensor HC-SR04 ............ <u>Amazon (https://amzn.to/2WedyNk)</u> / <u>Banggood</u>
   (<u>https://howtomechatronics.com/recommends/ultrasonic-sensor-hc-sr04-banggood/)</u>
- Breadboard and Jump Wires ....... <u>Amazon (https://amzn.to/2LYGILy)</u> / <u>Banggood</u>
   (https://howtomechatronics.com/recommends/breadboard-and-jump-wires-banggod/)

Disclosure: These are affiliate links. As an Amazon Associate I earn from qualifying purchases.

In order to generate the ultrasound you need to set the Trig on a High State for 10 µs. That will send out an 8 cycle sonic burst which will travel at the speed sound and it will be received in the Echo pin. The Echo pin will output the time in microseconds the sound wave traveled.


This website uses cookies to improve user experience. By using our website, you agree to our use of cookies.



(https://howtomechatronics.com/wp-

## content/uploads/2015/07/Ultrasonic-Sensor-Diagram.png)

For example, if the object is 10 cm away from the sensor, and the speed of the sound is 340 m/s or 0.034 cm/µs the sound wave will need to travel about 294 u seconds. But what you will get from the Echo pin will be double that number because the sound wave needs to travel forward and bounce backward. So in order to get the distance in cm we need to multiply the received travel time value from the echo pin by 0.034 and divide it by 2.



\_(https://howtomechatronics.com/wp-

content/uploads/2015/07/Ultrasonic-Sensor-Equasions.png)

### Arduino and HC-SR04 Ultrasonic Sensor Code

First you have to define the Trig and Echo pins. In this case they are the pins number 9 and 10 on the Arduino Board and they are named trigPin and echoPin. Then you need a Long variable, named "duration" for the travel time that you will get from the sensor and an integer variable for the distance.

```
1.  // defines pins numbers
2.  const int trigPin = 9;
3.  const int echoPin = 10;
4.
5.  // defines variables
6.  long duration;
7.  int distance;
```



In the setup you have to define the trigPin as an output and the echoPin as an Input and also start the serial communication for showing the results on the serial monitor.

```
This website uses cookies to improve user experience. By using our website, you agree to our use of cookies.

2. pinMode(trigPin, OUTPUT); // Sets the trigPin as an Output pinMode(echoPin, INPUT); // Sets the echoPin as an Input

3. pinMode(echoPin, INPUT); // Sets the echoPin as an Input
```

Serial.begin(9600); // Starts the serial communication

5.

In the loop first you have to make sure that the trigPin is clear so you have to set that pin on a LOW State for just 2 µs. Now for generating the Ultra sound wave we have to set the trigPin on HIGH State for 10 µs. Using the *pulseIn()* function you have to read the travel time and put that value into the variable "duration". This function has 2 parameters, the first one is the name of the echo pin and for the second one you can write either HIGH or LOW.

```
1.  // Clears the trigPin
2.  digitalWrite(trigPin, LOW);
3.  delayMicroseconds(2);
4.
5.  // Sets the trigPin on HIGH state for 10 micro seconds
6.  digitalWrite(trigPin, HIGH);
7.  delayMicroseconds(10);
8.  digitalWrite(trigPin, LOW);
```

In this case, HIGH means that the *pulsIn()* function will wait for the pin to go HIGH caused by the bounced sound wave and it will start timing, then it will wait for the pin to go LOW when the sound wave will end which will stop the timing. At the end the function will return the length of the pulse in microseconds.

For getting the distance we will multiply the duration by 0.034 and divide it by 2 as we explained this equation previously.


```
1.  // Reads the echoPin, returns the sound wave travel time in microseconds
2.  duration = pulseIn(echoPin, HIGH);
3.
4.  // Calculating the distance
5.  distance= duration*0.034/2;
6.
7.  // Prints the distance on the Serial Monitor
8.  Serial.print("Distance: ");
9.  Serial.println(distance);
```

At the end we will print the value of the distance on the Serial Monitor.

Here's the complete code:


```
1.
      * Ultrasonic Sensor HC-SR04 and Arduino Tutorial
2.
3.
      * by Dejan Nedelkovski,
 4.
      * www.HowToMechatronics.com
5.
6.
      */
7.
      // defines pins numbers
8.
9.
      const int trigPin = 9;
10.
      const int echoPin = 10;
11.
      // defines variables
12.
      long duration;
13.
      int distance;
14.
      void setup() {
      pinMode(trigPin, OUTPUT); // Sets the trigPin as an Output
15.
      pinMode(echoPin, INPUT); // Sets the echoPin as an Input
16.
      Serial.begin(9600); // Starts the serial communication
17.
18.
      }
19.
      void loop() {
20.
      // Clears the trigPin
21.
      digitalWrite(trigPin, LOW);
      delayMicroseconds(2);
22.
      // Sets the trigPin on HIGH state for 10 micro seconds
23.
24.
      digitalWrite(trigPin, HIGH);
25.
      delayMicroseconds(10);
26.
      digitalWrite(trigPin, LOW);
27.
      // Reads the echoPin, returns the sound wave travel time in microseconds
28.
      duration = pulseIn(echoPin, HIGH);
29.
      // Calculating the distance
30.
      distance= duration*0.034/2;
31.
      // Prints the distance on the Serial Monitor
      Serial.print("Distance: ");
32.
33.
      Serial.println(distance);
34.
```

This website uses cookies to improve user experience. By using our website, you agree to our use of cookies.




#### **Arduino Ultrasonic Sensor and LCD Display Example**

Here's another example how to use the ultrasonic sensor with Arduino and display the results on an LCD.



You can connect the ultrasonic sensor and the LDC as following:



(https://howtomechatronics.com/wp-

content/uploads/2015/07/Arduino-ultrasonic-sensor-and-the-LDC-circuit-diagram.png)

The code measuring the distance is pretty much the same as the basic example. Here, instead of printing the results on the serial monitor we print them on the LCD. If you need more details how to use and connect an LCD with Arduino

(<a href="https://howtomechatronics.com/tutorials/arduino/lcd-tutorial/">https://howtomechatronics.com/tutorials/arduino/lcd-tutorial/</a>) you can check my particular tutorial for it.

- This website uses cookies to improve user experience. By using our website, you agree to our use of cookies.
- 2. \* Ultrasonic Sensor HC-SR04 and Arduin Read more (https://howtomechatronics.com/privacy-policy-page/)
  3. \*

https://howtomechatronics.com/tutorials/arduino/ultrasonic-sensor-hc-sr04/

1.

```
* by Dejan Nedelkovski,
      * www.HowToMechatronics.com
 5.
 6.
7.
      #include <LiquidCrystal.h> // includes the LiquidCrystal Library
8.
      LiquidCrystal lcd(1, 2, 4, 5, 6, 7); // Creates an LCD object. Parameters: (rs, enable, d4, d5, d6, d7)
9.
      const int trigPin = 9;
10.
      const int echoPin = 10;
11.
12.
      long duration;
13.
      int distanceCm, distanceInch;
14.
      void setup() {
      lcd.begin(16,2); // Initializes the interface to the LCD screen, and specifies the dimensions (width and height) of the display
15.
      pinMode(trigPin, OUTPUT);
16.
      pinMode(echoPin, INPUT);
17.
18.
19.
      void loop() {
20.
      digitalWrite(trigPin, LOW);
21.
      delayMicroseconds(2);
22.
      digitalWrite(trigPin, HIGH);
      delayMicroseconds(10);
23.
24.
      digitalWrite(trigPin, LOW);
25.
      duration = pulseIn(echoPin, HIGH);
26.
      distanceCm= duration*0.034/2;
27.
      distanceInch = duration*0.0133/2;
      lcd.setCursor(0,0); // Sets the location at which subsequent text written to the LCD will be displayed
      lcd.print("Distance: "); // Prints string "Distance" on the LCD
      lcd.print(distanceCm); // Prints the distance value from the sensor
30.
31.
      lcd.print(" cm");
      delay(10);
32.
      lcd.setCursor(0,1);
33.
34.
      lcd.print("Distance: ");
35.
      lcd.print(distanceInch);
      lcd.print(" inch");
36.
37.
      delay(10);
38.
```

I hope you enjoyed this tutorial and learned something new. Feel free to ask any question in the comments section below and don't forget to <a href="mailto:check out my collection of Arduino Projects">check out my collection of Arduino Projects</a> (<a href="https://howtomechatronics.com/arduino-projects/">https://howtomechatronics.com/arduino-projects/</a>).



(https://www.pcbway.com/?

## from=howtomechatronics02)

Arduino (https://howtomechatronics.com/tag/arduino/)

HC-SR04 (https://howtomechatronics.com/tag/hc-sr04/)

Tutorial (https://howtomechatronics.com/tag/tutorial/)

## SHARE ON:

Share 117 Like 117

Save (https://in.pinterest.com/pin/create/button/?guid=2zhJcSThQLVy-1&url=https%3A%2F%2Fhowtomechatronics.com%2Ftutorials%2Farduino%2Fultrasonic-sensor-hc-

sr04%2F&media=https%3A%2F%2Fhowtomechatronics.com%2Fwp-content%2Fuploads%2F2015%2F07%2FUltrasonic-Sensor-Tutorial-

0001119.jpg&description=Ultrasonic%2BSensor%2BHC-SR04%2Band%2BArduino%2BTutorial)


Tweet

### **RELATED POSTS**

This website uses cookies to improve user experience. By using our website, you agree to our use of cookies.


Ok Read more (https://howtomechatronics.com/privacy-policy-page/)

25





(https://howtomechatronics.com/tutorials/arduino/arduino-and-hc-05-bluetooth-module-tutorial/)
This website uses cookies to improve user experience. By using our website, you agree to our use of cookies.



(https://howtomechatronics.com/tutorials/arduino/buttons-pwm/)



(https://howtomechatronics.com/tutorials/arduino/arduino-brushless-motor-control-tutorial-esc-bldc/)

# 95 RESPONSES

This website uses cookies to improve user experience. By using our website, you agree to our use of cookies.

<u>S Looney (https://howtomechatronics.com/tutorials/arduino/ultrasonic-sensor-hc-sr04/)</u> November 24, 2015 (https://howtomechatronics.com/tutorials/arduino/ultrasonic-sensor-hc-sr04/#comment-192)

Please note the error in your fritzing wiring diagram that shows GND to VCC and VCC to echo.

**Thanks** 

	_		- N/
к	-	$\mathbf{r}$	·v

<u>Dejan Nedelkovski (https://howtomechatronics.com)</u> November 25, 2015 (https://howtomechatronics.com/tutorials/arduino/ultrasonic-sensor-hc-sr04/#comment-209)

Thanks for the remark. I will change the that one.

REPLY

pradeep November 27, 2015 (https://howtomechatronics.com/tutorials/arduino/ultrasonic-sensor-hc-sr04/#comment-219)

Can you please email me the updated diagram of Ultrasonic Circuit sketch diagram?

Thank you in advance,

Pradeep

<u>Dejan Nedelkovski (https://howtomechatronics.com)</u> <u>November 27, 2015</u> (https://howtomechatronics.com/tutorials/arduino/ultrasonic-sensor-hc-sr04/#comment-220)

It's already updated.

*pictorobo* (https://www.pictorobo.com) April 13, 2017 (https://howtomechatronics.com/tutorials/arduino/ultrasonic-sensor-hc-sr04/#comment-1889)

connet vcc to +5 volt

**REPLY** 

<u>mujadidd (https://www.engr.com)</u> November 30, 2015 (https://howtomechatronics.com/tutorials/arduino/ultrasonic-sensor-hc-sr04/#comment-235)

please give us the diagram of the ultra sonic with LCD

REPLY

This website uses cookies to improve user experience. By using our website, you agree to our use of cookies.