

2W61	V-56900-10 3	SCHD	PME Isolation Switch -	Note:
Cut Out:		05/29/26 11:39		Establish new feeder load side of new PME 10 sourced by 2W15 and 2W17 Status of V-99265 needs to be verified. CPM to follow up on procedure to switch PME - don't energize without it
Station Ground:	On	Grounds:	1	
Dead Moves:	1	Taken Out:	0	
			PME-10 Load Side Feeder Supplied by Feeders 2W17 & 2W15	

Take Out			ID	Type	Equipment	G	Move		Response	Restore		
Op	Issued	Complete								Op	Issued	Complete
							De-load - Restore					
	05/29 11:20	05/29 11:20	A	ISO SW NO	V-56900-101		HILLVIEW AVE. PME-10 - Check Isolation Sw Open & Place S/T	S	695004			
			A	ISO SW NO	V-56900-101		HILLVIEW AVE. PME-10 - Phase Check	S			06/03 11:23	06/03 15:11
	05/29 05:45	05/29 05:45	A	ISO SW NC	V-56900-102		HILLVIEW AVE. PME-10 - Open Isolation Sw. & S/T	S	695005			
			A	ISO SW NC	V-56900-102		HILLVIEW AVE. PME-10 - Phase Check	S			06/03 16:18	06/03 16:18
							De-energize - Energize					
	05/29 11:39	05/29 11:39		ISO SW Source	V-56900-103	1	(Central Park Ave) - Open Isolation Switch & S/T - V-56900-103		695006			
							Dead moves					
			B	PADMNT	V-99265-101	1	(PADMNT) - Check Dead, Lift & Park Elbows & S/T	N				
							Locate fault					
							Identify					
	05/29 11:45	05/29 11:45		ISO SW Source	V-56900-103	1	(PME-10 Central Park Ave) - Check 103 Dead & Apply portable ground - V-56900-103					
							TO FOD: Check for common locations before TC is applied					
			A	ISO SW Source	V-56900-103	1	(PME-10 Central Park Ave) - Apply IATC for TC CONTINUITY & Remove Ground - V-56900-103					
	06/03 15:48	06/03 15:48	B	PADMNT	V-99265-101	1	(PADMNT) - Check Elbows Dead & Apply Portable Grounds	N				
							Out to work - Back from work					

2W61

V-56900
V-103 SCHED PME Isolation Switch -

Take Out			ID	Type	Equipment	G	Move		Response	Restore		
Op	Issued	Complete								Op	Issued	Complete
							To FCR:					
							Test					
				ISO SW Source	V-56900-103	1	(PME-10 Central Park Ave) - Ammeter Clear & Reground - V-56900-103					
							PFS					