HSE FIELD GUIDE | SERNEM PRO SERIES | SITE VALIDATION REQUIRED

SERNEM

HEALTH AND SAFETY RESOURCES

HOT WORK CRITICAL SAFETY RULES

AUTHORIZE • CONTROL COMBUSTIBLES • PREVENT FIRE

OSHA 1910.252(A)(2)(III)(B) | OSHA · US SCOPE | VERIFY LOCAL REQUIREMENTS SEPARATELY

DOCUMENT

SRN-HW-001

Revision 1.0

EN

SCAN

Open the digital poster library

SERNEM PRE-JOB CONTROL
CHECK BEFORE STARTING

PRE-JOB CHECK

- ✓ HOT WORK PERMIT
- ✓ REQUIRED GAS TESTING
- ✓ COMBUSTIBLE CONTROL
- ✓ FIRE WATCH
- ✓ SUITABLE EXTINGUISHER
- ✓ SPARK BARRIERS
- ✓ POST-WORK WATCH

01 — MANDATORY

HOT WORK PERMIT

- ✓ Verify a valid hot work permit.
- ✓ Confirm the work area and scope match the authorization.
- ✓ Stop work and reassess the permit if conditions change.

02 — MANDATORY

REMOVE COMBUSTIBLES

- ✓ Move combustible materials to a safe distance.
- ✓ Protect immovable materials with fire-resistant covers.
- ✓ Check floors, openings and opposite surfaces for spark exposure.

03 — MANDATORY

ATMOSPHERIC TESTING

- ✓ Test the atmosphere before work where required.
- ✓ Verify oxygen, flammable-gas and toxic hazards.
- ✓ Use continuous or periodic monitoring when conditions may change.

04 — MANDATORY

FIRE WATCH

- ✓ Assign a trained fire watch with no conflicting duties.
- ✓ Ensure all exposed areas remain visible and accessible.
- ✓ Authorize the fire watch to stop work and raise the alarm.

05 — WARNING

FIREFIGHTING EQUIPMENT

- ✓ Keep suitable extinguishing equipment immediately available.
- ✓ Verify equipment is inspected and ready for use.
- ✓ Confirm alarm and emergency communication arrangements.

06 — WARNING

CONTROL SPARKS AND HEAT

- ✓ Confine sparks, slag and hot fragments.
- ✓ Use fire curtains or suitable barriers.
- ✓ Assess heat conduction through walls, pipes and metal surfaces.

07 — WARNING

CYLINDER AND HOSE SAFETY

- ✓ Keep cylinders upright, secured and away from heat.
- ✓ Inspect hoses, regulators and connections before use.
- ✓ Keep oxygen equipment free from oil and grease.

08 — INFORMATION

POST-WORK FIRE WATCH

- ✓ US OSHA: maintain a fire watch for at least 30 minutes after welding/cutting requiring a watch.
- ✓ Extend the watch for stricter local rules, permits or risk; do not shorten the applicable OSHA minimum.
- ✓ Check concealed spaces and smouldering fires; do not end the watch while hazards remain.

CRITICAL STOP CRITERIA
STOP WORK NOW

STOP

- ✖ STOP WORK IMMEDIATELY IF THERE IS NO VALID HOT WORK PERMIT
- ✖ STOP WORK IF FLAMMABLE OR EXPLOSIVE ATMOSPHERIC HAZARDS ARE UNCONTROLLED
- ✖ STOP WORK IF COMBUSTIBLES ARE NOT REMOVED OR PROTECTED
- ✖ STOP WORK IF THERE IS NO FIRE WATCH OR SUITABLE EXTINGUISHING EQUIPMENT
- ✖ STOP WORK IF SPARKS AND HOT FRAGMENTS CANNOT BE CONTAINED

TECHNICAL CONTROL
CRITICAL CONTROLS

35 ft
OSHA WATCH CRITERION: COMBUSTIBLES <10.7 M; SPARK/HEAT HAZARDS BEYOND THIS DISTANCE ALSO COUNT

≥30 MIN
US OSHA: AFTER WELDING/CUTTING REQUIRING A WATCH; EXTEND FOR STRICTER RULES

PERMIT
VERIFY SCOPE AND CONDITIONS

WATCH
TRAINED AND READY

TECHNICAL REFERENCE · VALIDATION REQUIRED
OSHA 1910.252(a)(2)(iii)(B)
Verify source scope and local requirements

PERSONAL PROTECTIVE EQUIPMENT
RISK-BASED PPE SELECTION

- WELDING HELMET — PROCESS-MATCHED FILTER
- SAFETY GLASSES — EYE PROTECTION UNDER HELMET
- HEAT-RESISTANT GLOVES — HEAT AND SPATTER
- LEATHER FOOTWEAR — HOT METAL AND SPARKS
- FLAME-RESISTANT CLOTHING — PROCESS-MATCHED FLAME PROTECTION

SELECT PPE BY RISK, MANUFACTURER AND SITE PROCEDURE; THIS LIST IS NOT MANDATORY FOR EVERY TASK.

SERNEM
Better Safety, Better Tomorrow.

STOP WORK IF IT IS UNSAFE!

VERIFY SITE PROCEDURE
www.sernem.com