

HSE TOOLBOX TALK

ABRASIVE BLASTING

PURPOSE AND SCOPE

Control respirable dust, toxic coatings, high noise, recoil, hose failure and poor visibility during abrasive blasting through enclosure, extraction, supplied-air protection and area control.

KEY HAZARDS

1  RESPIRABLE DUST	2  SILICA	3  TOXIC COATING	4  HIGH NOISE
5  HOSE WHIP	6  RECOIL	7  POOR VISIBILITY	8  STATIC

CRITICAL VALUES TO VERIFY IN THE FIELD

100%

Deadman control and hose couplings

Hazard-specific

Supplied-air blasting helmet

0

Uncontrolled dust escape / unauthorized entry



REMEMBER - SERNEM

S

Stop and think

E

Evaluate the risk

R

Remove or reduce

N

Never assume

E

Ensure protection

M

Monitor and communicate

HSE TOOLBOX TALK

ABRASIVE BLASTING

STANDARDS AND FIELD REQUIREMENTS

OSHA 1910.94(a), 1910.134 and 1910.95 jointly address blasting enclosure/ventilation, respiratory protection, noise and safe equipment use.

OSHA 1910.94(a)

ENCLOSURE AND VENTILATION

Use a blast room/cabinet and effective exhaust dust-collection system that captures dust at source.

OSHA 1910.134

RESPIRATORY PROTECTION

Provide a supplied-air blasting helmet, breathing air and written program suitable for the contaminant and process.

OSHA 1910.95

NOISE CONTROL

Measure exposure and apply engineering controls, time limits and suitable hearing protection.

EKİPMAN TALİMATI

HOSE AND DEADMAN

Verify hoses, couplings, safety restraints, grounding and deadman control before each shift.


MINIMUM EVIDENCE BEFORE START

- | | |
|---|---|
| ☐ Coating / material analysis | ☐ Exposure assessment |
| ☐ Extraction-system inspection | ☐ Breathing-air quality record |
| ☐ Hose / deadman inspection | ☐ Area-isolation plan |

SUPERVISOR DISCUSSION POINTS

- What hazards are in the coating?
- What happens if the air supply fails?
- Were the deadman and extraction tested?

ENCLOSED BLASTING, EXTRACTION AND SUPPLIED-AIR PROTECTION



Enclosure - Extraction - Deadman - Hose restraint - Supplied air - Barrier

HSE TOOLBOX TALK

ABRASIVE BLASTING

CRITICAL CONTROL MEASURES (HIERARCHY OF CONTROLS)

1. SELECT A LESS HAZARDOUS ABRASIVE

Select a suitable lower-hazard, silica-free abrasive and enclosed method.

2. ENCLOSE AND EXTRACT

Operate the blast enclosure, negative pressure and dust collection.

3. SECURE THE EQUIPMENT

Inspect hoses, secure couplings, ground equipment and test the deadman control.

4. SUPPLIED AIR PPE AND AREA CONTROL

Use a supplied-air helmet, protective suit and hearing protection; isolate the area.

CRITICAL WARNING



Do not remove the blasting helmet or air supply in the exposure zone. Release the deadman and leave if pressure, dust or air quality is abnormal.

SITE CHECKLIST (BEFORE STARTING WORK)

- | | |
|---|--|
| ☐ Coating hazard known | ☐ Abrasive suitable |
| ☐ Extraction operating | ☐ Hose and coupling sound |
| ☐ Deadman works | ☐ Grounding verified |
| ☐ Breathing air verified | ☐ PPE complete |
| ☐ Area isolated | |

HSE TOOLBOX TALK

ABRASIVE BLASTING

ATTENDANCE AND APPROVAL

Project / Site:

Date:

Presented by:

Work area:

No	Full Name	Company / Role	Signature
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			