

Notes:

- 1. R1 must be pretinned before installation for reliable connections.
- 2. HN connector connects to R1 via miniature cup soldered onto end of R1 via miniature copper strip.
- 3. MHV connector connects to HV PCB via pin which goes through preamp PCB.



Title	Schematic 1: HE3 Detector Prean	np HV PCB Ver 3				
Size A	Document Number <doc></doc>					Rev 1.0
Date:	Monday, October 06, 2014	Sheet	1	o f	1	
	2	1				