
MMA7361 Triple Axis Accelerometer Breakout

From Geeetech Wiki

Contents

- 1 Introduction
- 2 Features
- 3 Document
- 4 Usage
- 5 Example code
- 6 How to buy

Introduction



This is a breakout for freescale mma73611 analog three axis accelerometer. The MMA7361L is a low power, low profile capacitive micromachined accelerometer featuring signal conditioning, a 1-pole low pass filter, temperature compensation, self test, 0g-Detect which detects linear freefall, and g-Select which allows for the selection between 2 sensitivities. Zero-g offset and sensitivity are factory set and require no external devices. The MMA7361L includes a Sleep Mode that makes it ideal for handheld battery powered electronics.

Features

- Low Voltage Operation: 2.2 V 3.6 V
- High Sensitivity (800 mV/g @ 1.5g)
- Selectable Sensitivity $(\pm 1.5g, \pm 6g)$
- Fast Turn On Time (0.5 ms Enable Response Time)
- Self Test for Freefall Detect Diagnosis
- 0g-Detect for Freefall Protection


- Signal Conditioning with Low Pass Filter
- Robust Design, High Shocks Survivability
- RoHS Compliant
- Environmentally Preferred Product
- Low Cost

Document

- MMA7361 library (http://code.google.com/p/mma7361-library/)
- MMA7361 Schematic
 (http://www.geeetech.com/Documents/MMA7361%20Module%20Schematic%20.pdf)
- MMA7361L Datasheet (http://www.geeetech.com/Documents/MMA7361L%20Datasheet.pdf)


Usage

Here is the guide illustrates how to connect an Arduino to the MMA7361 Triple Axis Accelerometer Breakout. The following is a table describing which pins on the Arduino should be connected to the pins on the accelerometer:



MMA7361	Uno/Duemilanove
sleepPin/SLEEP	13
selfTestPin/STP	12
zeroGPin/0G	11
gSelectPin/GSEL	10
xPin	AO
yPin	A1
zPin	A2
VDD	3.3V
GND	GND
	AREF -> 5V

First put on the MMA7361 module on the flat and upload the Arduino example code. Then open the serial monitor, after the calibrating, MMA 7361 will output the gravity on x, y and z axis. The photo below shows the output data when the accelerometer is lying flat, the gravity of Z axis is about 100(1 G). Please note keep this module flat when calibrating.



Example code

```
#include <AcceleroMMA7361.h>
AcceleroMMA7361 accelero;
int x;
int y;
int z;
woid setup()
{
   Serial.begin(9600);
   accelero.begin(13, 12, 11, 10, A0, A1, A2);
   accelero.setARefVoltage(5); //sets the AREF voltage to 3.3V
   accelero.setSensitivity(LOW); //sets the sensitivity to +/-6G
   accelero.calibrate();
}
```

```
void loop()
{
    x = accelero.getXAccel();
    y = accelero.getZAccel();
    z = accelero.getZAccel();
    Serial.print("\nx: ");
    Serial.print(x);
    Serial.print(y);
    Serial.print(y);
    Serial.print(" \tz: ");
    Serial.print(z);
    Serial.print("\td*10^-2");
    delay(500); //make it readable
}
```

How to buy

Click here to buy MMA7361 Triple Axis Accelerometer Breakout (http://www.geeetech.com/mma7361-triple-axis-accelerometer-breakout-p-399.html)

Retrieved from "http://www.geeetech.com/wiki/index.php? title=MMA7361 Triple Axis Accelerometer Breakout&oldid=2156"

- This page was last modified on 21 October 2012, at 18:49.
- This page has been accessed 8,682 times.