
Bell, Milton

Aug-20-2016

MEC/KMEC

d Enclosure-Standard Accessory Stiffening Column Installation




ASSEMBLY PROCEDURE

- 1. INSTALL 623A STIFFENING COLUMNS WITH WALL PANELS.
- 2. PLACE STIFFENING COLUMNS IN BASE CHANNEL & BOLT INTO PLACE WITH K1100B 3/8" RIB BOLT, K1100A RECT. NUT AND K190-4 WASHER. (USE HOLE IN STIFFENING COLUMN AS TEMPLATE WHEN FIELD DRILLING IS REQUIRED
- INSTALL WALL CAP OVER WALL PANELS & STIFFENING COLUMNS. BOLT TOGETHER WITH RIB BOLTS. (FIELD DRILLING REQUIRED)*
- 4. FASTEN PANEL RIB TO STIFFENING COLUMN WITH K1237-5 #12 FASTENER AT 2'-0" C/C.
- 5. FASTEN RIBS OF HEAD PANELS WITH K1235 #14 STITCH SCREWS. (MINIMUM 2 PER PANEL)
- * FOR ENDWALL OF TYPE 'AL' BUILDINGS, BOLT STIFFENING COLUMN TO ENDWALL GIRT. (FIELD DRILLING REQUIRED)


NOTES:

- 1. THIS STIFFENING KIT WILL NOT WORK IN A CORNER PANEL! REFER TO DRAWING CSK-1 FOR THIS APPLICATION.
- 2. FIELD DRILL ALL HOLES FOR 3/8" FIB BOLTS AS REQUIRED. ALL 3/8" PRIB BOLTS ARE: K1100B BOLT, K1100A RECT. NUT AND K190-4 WASHER.
- PRIOR TO CLOSING OFF ACCESS TO INTERIOR OF STIFFINING COLUMN, INSTALL INSULATION IF REQUIRED.



SECTION THRU DOOR

VOGT POWER INTERNATIONAL V17494-BEXD-5057-02 06-Aug-2016



REVISIONS	BY
01-07-98	CBP
12-10-03	RAP
01-24-05	DLR
11-07-06	BHKJ
01-11-07	BHKJ
03-04-09	JMC
02-23-2012	KRK
07-09-2013	RAP



ACCESSORY STIFFENING
KIT INSTALLATION

06-28-96

DETAILS

DATE DRAWN BY KAG NTS

SCALE ORDER NO.

REVISION 8

ASK-2

SEE STD. WALK -DOOR DETAIL FOR INSTALLATION OF K1313, 3½", R13 UNFACED FIBERGLASS -WALL PANEL INSULATION. SEE NOTE 3. NOTE: FIELD CUT RETURN LEG OFF ON OPPOSITE SIDE. K1237-5 #12 FASTENER @ 2'-0" C/C RETURN LEG SEE NOTE ABOVE K1100B RIB BOLT WITH K1100A RECT. NUT-K1100B RIB BOLT-BASE CHANNEL AND K190-4 FLAT WASHER (FIELD DRILL) WITH K1100A RECT. NUT AND K190-4 FLAT WASHER 623A STIFFENING COLUMN

BASE DETAIL