
MEC/KMEC

Enclosure-Standard Accessory Stiffening Column Installatio



## **ASSEMBLY PROCEDURE**


- 1. INSTALL 623A STIFFENING COLUMNS WITH WALL PANELS.
- 2. PLACE STIFFENING COLUMNS IN BASE CHANNEL & BOLT INTO PLACE WITH K1100B 3/8" RIB BOLT, K1100A RECT. NUT AND K190-4 WASHER. (USE HOLE IN STIFFENING COLUMN AS TEMPLATE WHEN FIELD DRILLING IS REQUIRED
- 3. INSTALL WALL CAP OVER WALL PANELS & STIFFENING COLUMNS. BOLT TOGETHER WITH RIB BOLTS. (FIELD DRILLING REQUIRED) \*
- 4. FASTEN PANEL RIB TO STIFFENING COLUMN WITH K1237-5 #12 FASTENER AT 2'-0" C/C.
- 5. FASTEN RIBS OF HEAD PANELS WITH K1235 #14 STITCH SCREWS. (MINIMUM 2 PER PANEL)
- \* FOR ENDWALL OF TYPE 'AL' BUILDINGS, BOLT STIFFENING COLUMN TO ENDWALL GIRT. (FIELD DRILLING REQUIRED)

## NOTES:

INSTALLATION OF

-BASE CHANNEL

- THIS STIFFENING KIT WILL NOT WORK IN A CORNER PANEL! REFER TO DRAWING CSK-1 FOR THIS APPLICATION.
- FIELD DRILL ALL HOLES FOR 3/8" RIB BOLTS AS REQUIRED. ALL 3/8" RIB BOLTS ARE: K1100B BOLT, K1100A RECT. NUT AND K190-4 WASHER.
- PRIOR TO CLOSING OFF ACCESS TO INTERIOR OF STIFFINING COLUMN, INSTALL INSULATION IF REQUIRED.





REVISIONS	BY
01-07-98	CBP
12-10-03	RAP
01-24-05	OUR
11-07-06	BHKJ
01-11-07	ВНКЈ
03-04-09	JMC
02-23-2012	KRK
07-09-2013	RAP



DATE 08-28-98 DRAWN BY KAG SCALE NTS

ORDER HO. REVISION

VOGT POWER INTERNATIONAL

V17494-BEXD-5092-02

08-Aug-2016

ASK-2

**SECTION THRU DOOR** 

K1313, 3½", R13 UNFACED FIBERGLASS WALL PANEL INSULATION. SEE NOTE 3. NOTE: FIELD CUT RETURN LEG OFF ON OPPOSITE SIDE. K1237-5 #12 FASTENER 9 2'-0" C/C RETURN LEG SEE NOTE ABOVE-

K1100B RIB BOLT-

WITH KI100A RECT. NUT AND K190-4 FLAT WASHER

**BASE DETAIL** 

K1100B RIB BOLT WITH K1100A RECT. NUT— AND K190-4 FLAT WASHER (FIELD DRILL)