



SHOWN FOR CLARITY

-623A STIFFENING COLUMN (SEE DRAWING ASK-2 FOR DETAILS.) NOTE: IF THIS PANEL IS ALSO A CORNER PANEL USE ADDITIONAL 220A CORNER SIFFENER HERE.



VOGT POWER INTERNATIONAL V17494-BEXD-5118-00 10-Aug-2016

BASE DETAIL



OL
UL
JAK
JM
TLO
JM(



OPENING CORNER FFENING COLUMN INSTALLATION ECTIONS AND DETAILS DATE 01-07-98 DRAWN BY SCALE MTS ORDER NO.

REVISION

CSK-1

ASSEMBLY PROCEDURE

STEP 1. FIELD CUT IN-TURNING RIB FROM CORNER PANEL & HEAD OR WALL PANEL.

STEP 2. INSULATE CORNER PANEL AND INSTALL STIFFENER STEP 3. BOLT STIFFENER INTO PLACE WITH 3/8" RIB BOLTS.

STEP 4. INSTALL WALL CAP OVER WALL PANELS AND STIFFENERS. BOLT TOGETHER WITH RIB BOLT (USE HOLES IN STIFFENER AS TEMPLATE FOR FIELD DRILLING.)

STEP 5. FASTEN PANEL RIB TO STIFFENER WITH K1237-5 FASTENER AT 2'-0" C/C.

STEP 6. FASTEN RIBS OF HEAD PANELS WITH K1235 STITCH SCREW (MINIMUM 2 PER PANEL.)