## Receiver Checklist

□ <u>MK6</u>
plug-in device
wait about 2 minutes
user
user
<u>PC</u>
python3 main.py rx 127.0.0.1 9000 1000 1000
□ <u>MK6</u>
kinematics-sample-client -a -n 1
wait about 2 sec
press ctrl-c
□ <u>PC</u>
press enter
type transmitter latitude
press enter
type transmitter longitude
press enter
□ <u>MK6</u>
while [1]; do echo \$EPOCHREALTIME; sleep 0.001; done
wait about 2 sec
press ctrl-c
□ <u>PC</u>
copy acme command
□ <u>MK6</u>
paste acme command
press enter
□ <u>PC</u>
press enter