Sort the screws before you start

4 ×

M3 × 6

PCB mounting

With 4 M3 washers, about 0.5 mm thick.

4 ×

M3 × 8

Lid mounting

Head diameter at most 6 mm.

2 ×

M2.5 × 8

Display blank

Pass through blank and lid.

4 ×

M3

Under PCB screw heads

Seat on the board, not below it.

2 ×

M2.5

Under the lid

Between lid underside and blank nuts.

2 ×

M2.5

Display blank retention

Hold while tightening the two screws.

Tools: ruler, deburring tool, M3 × 0.5 hand tap, suitable hand screwdriver and a small nut driver. Confirm actual screw drawings and fit on the coupon; no tightening torque is qualified.