11 Apply labels and record the build.

Apply the A1 label master. J1 is the supply input; output terminals are load connections.

Verify +24 V and 0 V/GND (–) against J1 pin numbers. There is no protective-earth connection.

Record printer settings, screw fit, switch retention, cable clearance and optical alignment. Update CAD under a new revision when needed.



Electrical operation requires the staged bring-up procedure and an A1 firmware port. Test the actual terminal behavior, switch cycling and temperatures; a lit PWR LED does not prove execution.