

COLLEGE OF ENGINEERING, DESIGN, ART AND TECHNOLOGY DEPARTMENT OF ELECTRICAL AND COMPUTER ENGINEERING SCHOOL OF ENGINEERING

November 22, 2023

BACHELOR OF SCIENCE IN ELECTRICAL ENGINEERING

ELE2111 MATLAB ASSIGNMENT

SHAWAL MBALIRE 21/U/0851

Question 1

Plot the Bode magnitude and phase for the system with transfer function

$$G_{(s)} = \frac{2000(s+0.5)}{s(s+10)(s+50)}$$

First we expand the function as a polynomial as matlab uses the polynomial version of the transfer function.

$$G_{(s)} = \frac{2000 \times s + 2000 \times 0.5}{s(s \times s + 10 \times s + 50 \times s + 10 \times 50)}$$
$$G_{(s)} = \frac{2000s + 1000}{s(s^2 + 10s + 50s + 500)}$$
$$G_{(s)} = \frac{2000s + 1000}{s^3 + 60s^2 + 500s}$$

The polynomial is then used to create a transfer function. The transfer function is then plotted using the bode function. The code is shown below.

```
% Define the transfer function
numerator = [2000, 1000];
denominator = [1, 60, 500, 0];

% Create a transfer function
sys = tf(numerator, denominator);

% Plot the Bode plot
figure;
bode(sys);
title('Bode-Plot');
grid on;
```

The resulting figure is shown below




Figure 1: Bode plot for G (s)

Question 2 Sketch the Bode plot (Magnitude and Phase Angle) for

$$H = \frac{10000(S+1)}{(S+10)(S+1000)}$$

First we expand the function as a polynomial as matlab uses the polynomial version of the transfer function.

$$H = \frac{10000(S+1)}{(S+10)(S+1000)}$$
$$H = \frac{10000S+10000}{S^2+1010S+10000}$$

The polynomial is then used to create a transfer function. The transfer function is then plotted using the bode function. The code is shown below.

```
% Plot the Bode plot
figure;

% Bode magnitude plot
bode(sys_H);
title('Bode-Magnitude-Plot-for-H(s)');
grid on;
```

The resulting figure is shown below




Figure 2: Bode plot for a H (s)

Question 3 Plot a Bode plot of a highpass filter with a gain of 0 dB and cutoff frequency of 3000 Hz.

Assume a first order continous implementation of a high pass filter. The transfer function is given by

$$H = \frac{s\tau}{s\tau + 1}$$
$$f = \frac{1}{2\pi\tau}$$

$$\tau = \frac{1}{2\pi f}$$

$$H = \frac{s\frac{1}{2\pi f}}{s\frac{1}{2\pi f} + 1}$$

$$H = \frac{s}{s + 2\pi f}$$

$$H = \frac{s}{s + 6000\pi}$$

$$DC \ Gain = \lim_{s \to 0} s \times \frac{s}{s + 6000\pi}$$

$$DC \ Gain = 0$$

The code is shown below.

```
gain = 0; % Gain in dB
cutoff_frequency = 3000; % Cutoff frequency in Hz

% Create a highpass filter transfer function
numerator_highpass = [1, 0]; % (s)
denominator_highpass = [1, 2 * pi * cutoff_frequency]; % (s + 2*pi*f)

% Create a transfer function
sys_highpass = tf(numerator_highpass, denominator_highpass);

% Plot the Bode plot
figure;

% Bode magnitude plot
bode(sys_highpass);
title('Bode Plot for Highpass Filter');
grid on;
```

The resulting figure is shown below




Figure 3: Bode plot for a highpass filter