PART NUMBERS 73840-BK. -BTL

73840-BK

1 OS Bypass Clutch Valve

1 Plunger Valve

1 Bypass Clutch Control Sleeve

4 Lubrication Plugs (1 extra)

73840-BTL Services 73840-BK only

1 Reamer


1 Reamer Jig

3 Drill Bits (for lube modification)

Also Available:

73840-MK


Master Kit includes



73840-MTL

Master Tool Kit includes

73840-RTL (services 73840-RK only) 73840-BTL (services 73840-BK only)



OEM VALVES

The OEM control sleeve & bypass bore wear, causing:


- Slip converter codes
- 628/1744 • Low lube pressure

(front lube)

- Bushing & planetary failure
- Low converter pressure
 Converter crowding, engine stall in D-R

LOCATION #2:

- No TCC apply when hot
- Slip converter codes 628/1744



SONNAX PLUG KIT Increases converter & rear lube psi Feed to lube is now from line psi Front Lube Differential Lube Sonnax Plug OEM Converter PSI Feed -Lengthened spool with Lengthened spool provides better support & prevents leakage exhaust slots provides continuous bore support Annular grooves prevent side loading Annular grooves prevent side loading Oversized valve

re-establishes valve/bore fit

NOTE: Repairing this sleeve or bore alone won't

- High line pressure runaway
- Harsh engagements
- Failsafe lube shutdown
- All lube concerns

Complete fix includes pressure regulators. **Both valve** assemblies in kit 73840-MK.

.062" usable .052" worn bore

Sag Test

adding the plugs improve these pressures!

To test for a worn bypass clutch control valve bore, install the OE valve backward, with large spool in the position it normally rides. If the valve is not centered and sags in the valve body, the bore is worn.

- You can use the drill bits from the kit to gauge bore wear.
- If the largest drill (.062") inserts below valve as pictured, the bore is worn but usable.
- The mid-size drill supplied (.052") should not insert below valve.
- Actual minimum clearance is .058".