







Site Applicability/Scope: This SOP applies to all personnel handling radioactive sources in Nuclear Medicine (NM) Departments in LMMI.

Lower Mainland Medical Imaging: Standard Operating Procedure

Hand Contamination Procedure: Nuclear Medicine Radiation Safety

If you discover contamination on your hands above background...





Measure your hands using a contamination meter with a valid QC report. Record CPS/CPM and TIME.





Wash your hands with lukewarm water and soap. Re-measure and record CPS/CPM and TIME.



Keep washing, measuring and recording the results until the counts are no longer decreasing or the results are less than double the background.

Record initial results on the Report Form: NM RS. Hand in the report to the Site RSO.



The Site RSO will calculate the estimated skin dose using the "Skin Contamination Dose Calculator" and report the incident to the Regional Radiation Safety Team.



If contamination is still present (more than double the background):



- Wear waterproof gloves to promote sweating and to prevent contamination from spreading
- Seek advice from SRSO and plan for re-monitoring until counts are less than double background. Record results on the RS Report Forms.



If the estimated skin dose is ABOVE:

- 25 mSv for a NEW
- 5 mSv for a non-NEW

Call Provincial Workplace Health Call Centre (PWHCC) 1-866-922-9464



(Note: You can contact the PWHCC for any skin contamination events, even if below 5 mSv)



If the estimated skin dose is ABOVE:

- 50 mSv for a NEW
- 5 mSv for a non-NEW

Regional RSO will report the incident to the CNSC.



Effective date: 21/OCT/2022

Document Owner: NM Regional RSO

Document Number: ABCD-21-16-90036

Review Date: 22/SEP/2022 Revision date: 22/SEP/2022 Approved by: NM RSC Version: 2.0 Page: 1 of 1