

FID-10: No Connection to Unit - Hardware Module: AHFII, AHLOA, AHLOB, AHFIG at LTE End

This document section is exclusively about Fault ID FID-10 occurring in Hardware Module AHFII, AHLOA, AHLOB, AHFIG at LTE End. Applicable SW is 25R3, 26R1, 26R2. Waiting Period is Immediate if NR Up. Use this file when query contains AHFII, AHLOA, AHLOB, AHFIG at LTE End.

Fault ID: FID-10

Hardware Module: AHFII, AHLOA, AHLOB, AHFIG at LTE End

Applicable SW: 25R3, 26R1, 26R2

Waiting Period: Immediate if NR Up

System Status: NR module is Up and Running. FID-10 observed at LTE End

Recovery Steps for AHFII, AHLOA, AHLOB, AHFIG at LTE End:

Step 1 for AHFII, AHLOA, AHLOB, AHFIG at LTE End: Perform Web-EM RMOD reset from NR for AHFII, AHLOA, AHLOB, AHFIG.

Important Transition Note for this Module:

During troubleshooting of FID-10 for this module, if FID-10 turns into FID-1850 / FID-23 / FID-2934 / FID-2935 / FID-2942, it means connectivity to RU is established. Action: Collect RU logs and snapshot at this point for R&D; investigation.

Keywords for retrieval: FID-10, AHFII, AHLOA, AHLOB, AHFIG, LTE End, NR Up, Web-EM RMOD reset, FID-1850, FID-23, FID-2934, FID-2935, FID-2942

--- END OF CHUNK FOR MODULE AHFII, AHLOA, AHLOB, AHFIG at LTE End ---