

FID-10: No Connection to Unit - Hardware Module: AHFII, AHLOA, AHLOB, AHFIG at NR End

This document section is exclusively about Fault ID FID-10 occurring in Hardware Module AHFII, AHLOA, AHLOB, AHFIG at NR End. Applicable SW is 25R3, 26R1, 26R2. Waiting Period is Immediate if LTE Up. Use this file when query contains AHFII, AHLOA, AHLOB, AHFIG at NR End.

Fault ID: FID-10

Hardware Module: AHFII, AHLOA, AHLOB, AHFIG at NR End

Applicable SW: 25R3, 26R1, 26R2

Waiting Period: Immediate if LTE Up

System Status: LTE module is Up and Running. FID-10 observed at NR End

Recovery Steps for AHFII, AHLOA, AHLOB, AHFIG at NR End:

Step 1 for AHFII, AHLOA, AHLOB, AHFIG at NR End: Perform pssreboot HW from LTE end using SSH for AHFII, AHLOA, AHLOB, AHFIG.

Important Transition Note for this Module:

During troubleshooting of FID-10 for this module, if FID-10 turns into FID-1850 / FID-23 / FID-2934 / FID-2935 / FID-2942, it means connectivity to RU is established. Action: Collect RU logs and snapshot at this point for R&D; investigation.

Keywords for retrieval: FID-10, AHFII, AHLOA, AHLOB, AHFIG, NR End, LTE Up, pssreboot HW, SSH, FID-1850, FID-23, FID-2934, FID-2935, FID-2942

--- END OF CHUNK FOR MODULE AHFII, AHLOA, AHLOB, AHFIG at NR End ---