

Arista Access Switch Alarm SOP - ALARM_9418

Node: Arista-Access-Mumbai-MH-44 | **Vendor:** Arista | **Severity:** Major | **Alarm Code:** ALARM_9418

Description

This SOP outlines the steps to diagnose and resolve the ALARM_9418 on Arista Access Switch Node ID: Arista-Access-Mumbai-MH-44.

Potential Root Causes

Cause	Probability
Failed Hardware Component	High
Software Misconfiguration	Medium
Environmental Factors	Low

Diagnostic Commands

```
show system internal alarm
show system internal error
show interface status
show controller cpu-history
```

Resolution Steps

Step 1: {'Step': 'Power cycle the device', 'Action': 'Power off the device, wait for 30 seconds, and then power it back on.'}

Step 2: {'Step': 'Check hardware components', 'Action': 'Inspect the device for any hardware issues and replace the faulty component if necessary.'}

Step 3: {'Step': 'Verify software configuration', 'Action': 'Run the command 'show running-config' to verify the software configuration and make necessary changes if necessary.'}

Step 4: {'Step': 'Check environmental factors', 'Action': 'Verify that the device is installed in a suitable environment and is not experiencing any environmental issues.'}

Post-Check Verification

```
show system internal alarm
show system internal error
show interface status
show controller cpu-history
```