

Cisco Access Switch Alarm SOP (ALARM_5706)

Node: Cisco-Access-Chennai-TN-108 | **Vendor:** Cisco | **Severity:** Major | **Alarm Code:** ALARM_5706

Description

This SOP outlines the steps to diagnose and resolve the ALARM_5706 error on Cisco Access Switch Node ID: Cisco-Access-Chennai-TN-108

Potential Root Causes

Cause	Probability
Spanning Tree Protocol (STP) Loop	High
Port Channel Misconfiguration	Medium
Switch Stacked Unit (SSU) Failure	Low

Diagnostic Commands

```
show spanning-tree detail
show spanning-tree interface
show interface trunk
show interface status
show switch stack
show switch stack-ports
```

Resolution Steps

- Step 1: {'Step': '1. Identify and remove any STP loops', 'Action': 'Use the "show spanning-tree detail" command to identify any loops. Then, use the "spanning-tree root-port" command to set a new root port.'}
- Step 2: {'Step': '2. Verify port channel configuration', 'Action': 'Use the "show interface trunk" command to verify the port channel configuration. Make any necessary adjustments using the "interface range" command.'}
- Step 3: {'Step': '3. Check SSU status', 'Action': 'Use the "show switch stack" command to verify the SSU status. If the SSU is faulty, replace it with a new one using the "switch stack-member 1 replace" command.'}
- Step 4: {'Step': '4. Save configuration and reload the switch', 'Action': 'Save the configuration using the "copy running-config startup-config" command. Then, reload the switch using the "reload" command.'}

Post-Check Verification

```
show spanning-tree detail
show spanning-tree interface
show interface trunk
show interface status
show switch stack
```