

Alarm Response Procedure for Cisco-Access-Chennai-TN-108

Node: Cisco-Access-Chennai-TN-108 | **Vendor:** Cisco | **Severity:** Critical | **Alarm Code:** ALARM_6500

Description

This SOP outlines the steps to be taken in response to the Critical ALARM_6500 on Cisco-Access-Chennai-TN-108, an Access Switch.

Potential Root Causes

Cause	Probability
Hardware failure in the switch or a connected device	High
Misconfigured VLAN settings or spanning tree	Medium
Software bug or firmware issue	Low

Diagnostic Commands

```
show logging | include ALARM_6500
show int status | include ALARM_6500
show ip int brief | include ALARM_6500
show run | include ALARM_6500
debug platform software
```

Resolution Steps

- Step 1: {'Step': 'Restart the switch', 'Description': 'Restart the Cisco-Access-Chennai-TN-108 switch to clear any temporary issues.', 'Command': 'reload'}
- Step 2: {'Step': 'Check VLAN and spanning tree configurations', 'Description': 'Verify that VLAN and spanning tree configurations are correct and not misconfigured.', 'Command': 'show vlan | show spanning-tree'}
- Step 3: {'Step': 'Update firmware or software', 'Description': 'Update the firmware or software to the latest version to address any known bugs or issues.', 'Command': 'archive download-sw /overwrite /force-reload tftp:///image.bin'}
- Step 4: {'Step': 'Replace faulty hardware', 'Description': 'Replace any faulty hardware components, such as the power supply or fan tray.', 'Command': 'no shutdown'}

Post-Check Verification

```
show logging | include ALARM_6500 (to confirm the alarm has cleared)
show ip int brief | include ALARM_6500 (to verify network
connectivity)
show vlan | show spanning-tree (to verify VLAN and spanning tree
configurations)
```