

SOP for Cisco Access Switch ALARM_3133 in Delhi NCR - Node ID: Cisco-Access-Delhi-NCR-20

Node: Cisco-Access-Delhi-NCR-20 | **Vendor:** Cisco | **Severity:** Warning | **Alarm Code:** ALARM_3133

Description

This Standard Operating Procedure (SOP) outlines the steps to resolve the ALARM_3133 (Warning) on Cisco Access Switch Cisco-Access-Delhi-NCR-20 in Delhi NCR.

Potential Root Causes

Cause	Probability
Misconfigured Spanning Tree Protocol (STP)	High
Faulty or malfunctioning Gigabit Interface Converter (GBIC)	Medium
Insufficient power supply to the switch	Low

Diagnostic Commands

```
show spanning-tree interface
show interfaces gigabitethernet 0/0/0
show power inline interface
show inventory
```

Resolution Steps

- Step 1: {'Step': '1. Check the spanning tree configuration and ensure it is correctly configured.', 'Action': 'show running-config | include spanning-tree'}
- Step 2: {'Step': '2. Verify the GBIC module is properly seated and functioning.', 'Action': 'show inventory | include GBIC'}
- Step 3: {'Step': '3. Check the power supply to the switch and ensure it is functioning correctly.', 'Action': 'show power inline interface'}
- Step 4: {'Step': '4. If the issue persists, reset the switch to its default configuration.', 'Action': 'copy run start'}

Post-Check Verification

```
show spanning-tree interface
show interfaces gigabitethernet 0/0/0
show power inline interface
```