

Cisco-Access-Delhi-NCR-26 SOP for Alarm

ALARM_9503

Node: Cisco-Access-Delhi-NCR-26 | **Vendor:** Cisco | **Severity:** Warning | **Alarm Code:** ALARM_9503

Description

This SOP describes the procedure to troubleshoot and resolve the ALARM_9503 (Warning) on Cisco-Access-Delhi-NCR-26, an access switch.

Potential Root Causes

Cause	Probability
High CPU utilization caused by a stuck CPU process	High
Misconfigured routing protocol timers	Medium
Hardware failure of the switch	Low

Diagnostic Commands

```
show processes cpu
show processes memory
show ip protocols
show run | i routing timers
```

Resolution Steps

- Step 1: {'Step': '1. Check CPU utilization', 'Action': "Run 'show processes cpu' command.", 'CLI_Command': 'show processes cpu'}
- Step 2: {'Step': '2. Verify stuck CPU process', 'Action': 'Check if any process is stuck (running for more than 30 seconds).', 'CLI_Command': 'show processes cpu | i stuck'}
- Step 3: {'Step': '3. Restart stuck CPU process', 'Action': "Use 'process restart' command to restart the stuck process.", 'CLI_Command': 'process restart '}
- Step 4: {'Step': '4. Check routing protocol timers', 'Action': 'Verify if routing protocol timers are correctly configured.', 'CLI_Command': 'show ip protocols'}
- Step 5: {'Step': '5. Adjust routing protocol timers', 'Action': 'Adjust timers as necessary to prevent alarm recurrence.', 'CLI_Command': 'router eigrp 10 timer hello timer dead '}
- Step 6: {'Step': '6. Check hardware logs', 'Action': 'Verify for any hardware failure logs.', 'CLI_Command': 'show logging'}

Step 7: {'Step': '7. Replace faulty hardware (if necessary)', 'Action': 'Replace the faulty hardware component.', 'Note': 'This step should be performed by authorized personnel only.'}

Post-Check Verification

```
show processes cpu
show ip protocols
show run | i routing timers
```