

Standard Operating Procedure for Resolving ALARM_8187 on Cisco-Access-Mumbai-MH-52

Node: Cisco-Access-Mumbai-MH-52 | **Vendor:** Cisco | **Severity:** Major | **Alarm Code:** ALARM_8187

Description

ALARM_8187 indicates a major issue on Cisco-Access-Mumbai-MH-52, a Cisco Access Switch. This SOP outlines the steps to diagnose and resolve the issue.

Potential Root Causes

Cause	Probability
Misconfigured Spanning Tree Protocol (STP)	High
Hardware failure in the switch or uplink	Medium
Software bug or issue with the switch firmware	Low

Diagnostic Commands

```
show spanning-tree detail
show interface status
show tech-support
show log | include ALARM_8187
```

Resolution Steps

- Step 1: {'Step': '1. Check the switch logs for any errors related to ALARM_8187', 'Action': 'show log | include ALARM_8187'}
- Step 2: {'Step': '2. Verify the STP configuration and ensure it is correct', 'Action': 'show spanning-tree detail'}
- Step 3: {'Step': '3. Check for any hardware failures in the switch or uplink', 'Action': 'show interface status'}
- Step 4: {'Step': '4. If software bug suspected, check for firmware updates and apply if necessary', 'Action': 'show version | include Version'}
- Step 5: {'Step': '5. If issue still persists, gather tech-support data for further analysis', 'Action': 'show tech-support'}

Post-Check Verification

```
show spanning-tree detail
```

```
show interface status
show version | include Version
show log | include ALARM_8187
```