

Ericsson Access Switch ALARM_5000 Minor Alarm Root Cause and Resolution SOP

Node: Ericsson-Access-Bangalore-KA-64 | **Vendor:** Ericsson | **Severity:** Minor | **Alarm Code:** ALARM_5000

Description

This SOP outlines the steps to diagnose and resolve the ALARM_5000 Minor Alarm on the Ericsson Access Switch Node Ericsson-Access-Bangalore-KA-64.

Potential Root Causes

Cause	Probability
Interface Card Failure	Medium
Software Bug	Low
Hardware Issue	Medium

Diagnostic Commands

```
show interface status
show log | include ALARM_5000
show card status
show software version
```

Resolution Steps

- Step 1: {'Step': 'Replace Interface Card', 'Actions': ['Replace the faulty interface card with a new one.', 'Verify the new card is properly seated and secured.'], 'CLI_Commands': ['insert slot 1 card 1-1-1']}
- Step 2: {'Step': 'Reboot the Node', 'Actions': ['Reboot the Ericsson Access Switch Node to clear any software bugs or issues.', 'Monitor the node for any further alarms or issues.'], 'CLI_Commands': ['shutdown', 'no shutdown']}
- Step 3: {'Step': 'Upgrade Software', 'Actions': ['Upgrade the software to the latest version to resolve any software bugs.', 'Verify the software upgrade was successful.'], 'CLI_Commands': ['software upgrade', 'show software version']}

Post-Check Verification

```
show interface status
show log | include ALARM_5000
show card status
```

```
show software version
```