

Standard Operating Procedure for Ericsson Access Switch ALARM_5127

Node: Ericsson-Access-Chennai-TN-92 | **Vendor:** Ericsson | **Severity:** Major | **Alarm Code:** ALARM_5127

Description

This SOP outlines the steps to diagnose and resolve the ALARM_5127 (Major) on Ericsson Access Switch node Ericsson-Access-Chennai-TN-92.

Potential Root Causes

Cause	Probability
Faulty Network Interface Card (NIC)	High
Misconfigured Network Settings	Medium
Hardware Failure	Low

Diagnostic Commands

```
show interface | include errors
show ip interface brief | include errors
show network interface | include errors
show system redundancy | include errors
```

Resolution Steps

- Step 1: {'Step': 'Perform a hard reset of the node to clear any temporary issues.', 'Action': 'system reset force'}
- Step 2: {'Step': 'Verify the network interface card is properly seated and all connections are secure.', 'Action': 'show network interface | include status'}
- Step 3: {'Step': 'Re-configure the network settings to the recommended defaults.', 'Action': 'config network default'}
- Step 4: {'Step': 'Replace the faulty Network Interface Card (NIC) if hardware failure is confirmed.', 'Action': 'system shutdown ; replace '}

Post-Check Verification

```
show interface | include errors
show network interface | include errors
```

```
show system redundancy | include errors
```