

Ericsson Access Switch Delhi NCR Node 32 SOP for ALARM_1203

Node: Ericsson-Access-Delhi-NCR-32 | **Vendor:** Ericsson | **Severity:** Minor | **Alarm Code:** ALARM_1203

Description

This SOP outlines the procedures to diagnose and resolve the ALARM_1203 issue on the Ericsson Access Switch Delhi NCR Node 32.

Potential Root Causes

Cause	Probability
Faulty Optics	Medium
Incorrect Configuration	High
Hardware Failure	Low

Diagnostic Commands

```
show optics status
show config
show hardware status
```

Resolution Steps

- Step 1: {'Step': 'Check Optics Status', 'Action': "Run the command 'show optics status' to verify the optics status.", 'CLI_Command': 'show optics status'}
- Step 2: {'Step': 'Verify Configuration', 'Action': 'Check the configuration for any errors or inconsistencies.', 'CLI_Command': 'show config'}
- Step 3: {'Step': 'Replace Faulty Optics', 'Action': 'Replace the faulty optics with a new one.', 'CLI_Command': 'no optics enable'}
- Step 4: {'Step': 'Reconfigure the Switch', 'Action': 'Reconfigure the switch according to the documentation.', 'CLI_Command': 'config replace'}
- Step 5: {'Step': 'Verify Hardware Status', 'Action': "Run the command 'show hardware status' to verify the hardware status.", 'CLI_Command': 'show hardware status'}

Post-Check Verification

```
show optics status
```

```
show config
show hardware status
```