

Standard Operating Procedure for Ericsson Access Switch Alarm ALARM_3477

Node: Ericsson-Access-Delhi-NCR-36 | **Vendor:** Ericsson | **Severity:** Warning | **Alarm Code:** ALARM_3477

Description

This SOP outlines the steps to diagnose and resolve the ALARM_3477 on Ericsson-Access-Delhi-NCR-36 Access Switch, a Vendor Ericsson device.

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Incorrect Configuration	Medium
Hardware Failure	Low

Diagnostic Commands

```
show system status
show cpu usage
show config all
show log | include ALARM_3477
```

Resolution Steps

- Step 1: {'Step': 1, 'Action': "Check CPU utilization on the switch using 'show cpu usage' command."}
- Step 2: {'Step': 2, 'Action': "If CPU utilization is high, restart the switch using 'reboot system' command."}
- Step 3: {'Step': 3, 'Action': "Verify the configuration on the switch using 'show config all' command."}
- Step 4: {'Step': 4, 'Action': "If configuration is incorrect, update it correctly and verify using 'show config all' command."}
- Step 5: {'Step': 5, 'Action': 'If none of the above steps resolve the issue, perform hardware troubleshooting.'}

Post-Check Verification

```
show system status
show cpu usage
```

```
show config all  
show log | include ALARM_3477
```