

Ericsson Access Switch Alarm SOP (ALARM_9214)

Node: Ericsson-Access-Delhi-NCR-36 | **Vendor:** Ericsson | **Severity:** Major | **Alarm Code:** ALARM_9214

Description

Standard Operating Procedure for resolving ALARM_9214 on Ericsson Access Switch (Node ID: Ericsson-Access-Delhi-NCR-36)

Potential Root Causes

Cause	Probability
Hardware failure	High
Software configuration issue	Medium
Optical fiber damage	Low

Diagnostic Commands

```
show system status
show interface status
show optic status
show alarm history
checklog -s ALARM_9214
```

Resolution Steps

- Step 1: {'Step': '1. Identify the affected interface', 'Action': "Run 'show interface status' command to identify the affected interface."}
- Step 2: {'Step': '2. Check optical fiber integrity', 'Action': "Run 'show optic status' command to verify optical fiber integrity. If damage is detected, replace the fiber."}
- Step 3: {'Step': '3. Reboot the node', 'Action': "Run 'reboot node' command to reboot the node and clear the alarm."}
- Step 4: {'Step': '4. Verify software configuration', 'Action': "Run 'show system status' command to verify software configuration. If the issue is software-related, reconfigure or upgrade the software as necessary."}

Post-Check Verification

```
show system status
show interface status
```

```
show optic status  
show alarm history
```