

Ericsson Access Switch ALARM_5837 Resolution SOP

Node: Ericsson-Access-Kolkata-WB-114 | **Vendor:** Ericsson | **Severity:** Critical | **Alarm Code:** ALARM_5837

Description

This SOP outlines the steps to resolve the critical alarm ALARM_5837 on Ericsson Access Switch Node ID: Ericsson-Access-Kolkata-WB-114.

Potential Root Causes

Cause	Probability
High CPU utilization	High
Incorrect configuration	Medium
Hardware issue	Low

Diagnostic Commands

```
show cpu utilization
show config | include ALARM_5837
show tech-support | include ALARM_5837
```

Resolution Steps

- Step 1: {'Step': 'Check CPU utilization', 'Action': "Use the command 'show cpu utilization' to check if the CPU is overloaded.", 'CLI_Command': 'show cpu utilization'}
- Step 2: {'Step': 'Verify configuration', 'Action': "Use the command 'show config | include ALARM_5837' to verify if the configuration is correct.", 'CLI_Command': 'show config | include ALARM_5837'}
- Step 3: {'Step': 'Restart the node', 'Action': "Use the command 'reboot' to restart the node.", 'CLI_Command': 'reboot'}
- Step 4: {'Step': 'Replace hardware', 'Action': 'If the issue persists, replace the faulty hardware.', 'Action_Description': 'Contact the vendor for replacement hardware.'}

Post-Check Verification

```
show cpu utilization
show config | include ALARM_5837
show tech-support | include ALARM_5837
```