

Ericsson Access Switch ALARM_6896 Root Cause Identification and Resolution SOP

Node: Ericsson-Access-Kolkata-WB-118 | **Vendor:** Ericsson | **Severity:** Minor | **Alarm Code:** ALARM_6896

Description

This SOP outlines the steps to identify and resolve the ALARM_6896 on Ericsson Access Switch Node Ericsson-Access-Kolkata-WB-118.

Potential Root Causes

Cause	Probability
Incorrect DSLAM configuration	Medium
Faulty or misconfigured Network Interface Cards (NICs)	Low
Inadequate or incorrect cabling	Low

Diagnostic Commands

```
show dslam status
show interface status
show run | include ALARM_6896
show tech-support
```

Resolution Steps

- Step 1: {'Step': 'Verify DSLAM configuration', 'Action': "Check the DSLAM configuration using the command 'show dslam status' and verify that it matches the recommended configuration.", 'CLI_Commands': ['config dslam ']}
- Step 2: {'Step': 'Replace faulty or misconfigured NICs', 'Action': "Replace the faulty or misconfigured NICs with new ones and reconfigure the interface using the command 'config interface '.", 'CLI_Commands': ['config interface ']}
- Step 3: {'Step': 'Verify cabling', 'Action': 'Verify that the cabling is adequate and correctly connected.', 'CLI_Commands': []}

Post-Check Verification

```
show dslam status
show interface status
show run | include ALARM_6896
```