

Alarm Handling SOP for Ericsson Access Switch Kolkata WB 124

Node: Ericsson-Access-Kolkata-WB-124 | **Vendor:** Ericsson | **Severity:** Warning | **Alarm Code:** ALARM_9636

Description

This SOP outlines the procedures to handle ALARM_9636 on Ericsson Access Switch Kolkata WB 124.

Potential Root Causes

Cause	Probability
Hardware Failure in the Switch	High
Software Glitch in the Router	Medium
Misconfigured Network Settings	Low

Diagnostic Commands

```
show system status
show interface status
show log messages | include ALARM_9636
show version
```

Resolution Steps

- Step 1: {'Step': '1. Check System Status', 'Action': 'Run show system status command to verify the switch status.', 'CLI_Command': 'show system status'}
- Step 2: {'Step': '2. Check Interface Status', 'Action': 'Run show interface status command to verify the interface status.', 'CLI_Command': 'show interface status'}
- Step 3: {'Step': '3. Check Log Messages', 'Action': 'Run show log messages | include ALARM_9636 command to find the error message.', 'CLI_Command': 'show log messages | include ALARM_9636'}
- Step 4: {'Step': '4. Check Software Version', 'Action': 'Run show version command to verify the software version.', 'CLI_Command': 'show version'}
- Step 5: {'Step': '5. Check Network Settings', 'Action': 'Verify network settings, such as IP addresses and subnet masks.', 'CLI_Command': ''}
- Step 6: {'Step': '6. Restart the Switch', 'Action': 'Restart the switch using the reload command.', 'CLI_Command': 'reload'}

Post-Check Verification

```
show system status  
show interface status  
show log messages | include ALARM_9636
```