

Ericsson Access Switch Node Mumbai-MH-46 Minor Alarm Resolution SOP

Node: Ericsson-Access-Mumbai-MH-46 | **Vendor:** Ericsson | **Severity:** Minor | **Alarm Code:** ALARM_3236

Description

This SOP outlines the steps to diagnose and resolve Minor Alarm ALARM_3236 on Ericsson Access Switch Node Mumbai-MH-46.

Potential Root Causes

Cause	Probability
Invalid or missing configuration parameters	Medium
Hardware issues with the interface or cards	Low
Software flaws or bugs	Low

Diagnostic Commands

```
show tech-support
show alarm history
show interface stats
show card status
```

Resolution Steps

- Step 1: {'Step': 'Gather detailed technical support data', 'Action': "Run 'show tech-support' command to collect detailed system information."}
- Step 2: {'Step': 'Check alarm history', 'Action': "Run 'show alarm history' command to identify if this is a recurring issue."}
- Step 3: {'Step': 'Verify interface and card status', 'Action': "Run 'show interface stats' and 'show card status' commands to check for any hardware issues."}
- Step 4: {'Step': 'Verify configuration parameters', 'Action': 'Verify configuration parameters for the affected interface or card.'}
- Step 5: {'Step': 'Update or re-apply configuration', 'Action': 'Re-apply the correct configuration parameters if found to be invalid or missing.'}
- Step 6: {'Step': 'Reboot the node if necessary', 'Action': 'Reboot the node if any software or hardware issues are detected.'}

Post-Check Verification

```
show alarm history  
show interface stats  
show card status  
show configuration
```