

Ericsson Access Switch Node Alarm SOP for ALARM_5278

Node: Ericsson-Access-Mumbai-MH-46 | **Vendor:** Ericsson | **Severity:** Minor | **Alarm Code:** ALARM_5278

Description

This SOP outlines the procedures for investigating and resolving minor alarm ALARM_5278 on Ericsson Access Switch Node Ericsson-Access-Mumbai-MH-46.

Potential Root Causes

Cause	Probability
Invalid or missing software configuration	High
Misconfigured interface settings	Medium
Hardware malfunction or faulty component	Low

Diagnostic Commands

```
show tech-support
show interface
show version
show run
debug interface
```

Resolution Steps

- Step 1: {'Step': '1. Check system logs for recent errors or warnings', 'Action': 'show log'}
- Step 2: {'Step': '2. Verify software configuration and ensure it matches the recommended settings', 'Action': 'show run | include '}
- Step 3: {'Step': '3. Reconfigure interface settings as per the recommended settings', 'Action': 'interface no '}
- Step 4: {'Step': '4. Check for hardware malfunctions or faulty components and replace as necessary', 'Action': 'replace '}

Post-Check Verification

```
show interface
show version
```

```
show run | include
```