

Ericsson Access Switch SOP for Alarm Code

ALARM_7623

Node: Ericsson-Access-Mumbai-MH-52 | **Vendor:** Ericsson | **Severity:** Critical | **Alarm Code:** ALARM_7623

Description

This SOP outlines the procedures to follow when encountering the ALARM_7623 (Critical) on the Ericsson Access Switch in Mumbai, MH-52.

Potential Root Causes

Cause	Probability
Hardware Failure: Power Supply Unit (PSU) malfunction	High
Software Failure: Configuration issue or firmware bug	Medium
Environmental Factors: Power fluctuations or overheating	Low

Diagnostic Commands

```
show clock
show version
show power status
show temperature status
show system log | include ALARM_7623
```

Resolution Steps

- Step 1: {'Step': '1. Check power supply status and replace if faulty', 'Action': "Run 'show power status' to identify faulty PSU, and replace it with a spare unit."}
- Step 2: {'Step': '2. Verify configuration and firmware versions', 'Action': "Run 'show version' and 'show system log' to check for any configuration or firmware issues."}
- Step 3: {'Step': '3. Perform a system reset and reconfigure if necessary', 'Action': "Run 'reset system' and reconfigure the device if configuration changes are required."}
- Step 4: {'Step': '4. Check for environmental factors and take corrective actions', 'Action': 'Check for power fluctuations and overheating, and take corrective actions to prevent recurrence.'}

Post-Check Verification

```
show power status
```

```
show temperature status
show system log | include ALARM_7623
show version
```