

SOP for Resolving ALARM_5351 on Ericsson Provider Edge Router

Node: Ericsson-PE-Mumbai-MH-45 | **Vendor:** Ericsson | **Severity:** Critical | **Alarm Code:** ALARM_5351

Description

ALARM_5351 on Ericsson Provider Edge Router indicates a critical issue with the node Ericsson-PE-Mumbai-MH-45. This SOP provides a step-by-step guide to diagnose and resolve the issue.

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Memory Leak	Medium
Interface Flapping	Low

Diagnostic Commands

```
show cpu utilization
show memory
show interfaces status
show ip bgp summary
show ip cef detail
```

Resolution Steps

- Step 1: {'Step': 'Step 1: Check CPU Utilization', 'Description': 'Verify if CPU utilization is high. If high, proceed to Step 2.', 'Commands': ['show cpu utilization']}
- Step 2: {'Step': 'Step 2: Check for Memory Leak', 'Description': 'Verify if memory is leaking. If memory is leaking, proceed to Step 3.', 'Commands': ['show memory']}
- Step 3: {'Step': 'Step 3: Check for Interface Flapping', 'Description': 'Verify if any interfaces are flapping. If interfaces are flapping, proceed to Step 4.', 'Commands': ['show interfaces status']}
- Step 4: {'Step': 'Step 4: Clear BGP Sessions', 'Description': 'Clear BGP sessions on the node', 'Commands': ['clear bgp * soft']}
- Step 5: {'Step': 'Step 5: Reset CEF', 'Description': 'Reset CEF on the node', 'Commands': ['clear ip cef']}

Post-Check Verification

```
show cpu utilization
show memory
show interfaces status
show ip bgp summary
show ip cef detail
```