

Huawei Access Switch Alarm Handling - ALARM_8968

Node: Huawei-Access-Chennai-TN-100 | **Vendor:** Huawei | **Severity:** Minor | **Alarm Code:** ALARM_8968

Description

This SOP outlines the procedures to diagnose, resolve, and verify a minor alarm (ALARM_8968) on the Huawei Access Switch (Node ID: Huawei-Access-Chennai-TN-100).

Potential Root Causes

Cause	Probability
Optical Module Failure	High
Cable Fault	Medium
Switch Configuration Issue	Low

Diagnostic Commands

```
display current-alarms
display system internal info
display optical-module info
display interface info
```

Resolution Steps

- Step 1: {'Step': '1. Check the alarm status and log', 'Action': "Run the command 'display current-alarms' to identify the alarm and its log."}
- Step 2: {'Step': '2. Verify the optical module status', 'Action': "Run the command 'display optical-module info' to check the status of the optical module."}
- Step 3: {'Step': '3. Replace the optical module (if faulty)', 'Action': "Replace the optical module with a new one and verify the status using the command 'display optical-module info'."}
- Step 4: {'Step': '4. Check the cable connection', 'Action': 'Verify the cable connection between the switch and the optical module.'}
- Step 5: {'Step': '5. Reconfigure the switch (if necessary)', 'Action': "Run the command 'system-view' followed by 'interface [interface name]' to reconfigure the switch, if necessary."}

Post-Check Verification

```
display current-alarms
display system internal info
display optical-module info
display interface info
```