

# Huawei Access Switch Alarm Handling SOP for ALARM\_1428

**Node:** Huawei-Access-Delhi-NCR-12 | **Vendor:** Huawei | **Severity:** Critical | **Alarm Code:** ALARM\_1428

## Description

This SOP outlines the steps to identify, diagnose, and resolve the ALARM\_1428 (Severity: Critical) on the Huawei-Access-Delhi-NCR-12 node.

## Potential Root Causes

| Cause                                               | Probability |
|-----------------------------------------------------|-------------|
| Optical fiber damage or misconnection               | High        |
| Faulty Optical Transceiver                          | Medium      |
| Configuration mismatch between Optical Transceivers | Low         |

## Diagnostic Commands

```
display transceiver status
display optical link status
display optical transceiver information
```

## Resolution Steps

- Step 1: {'Step': '1. Check the connection and integrity of the optical fiber', 'Action': 'Verify the connection and inspect the fiber for any damage or misconnection.'}
- Step 2: {'Step': '2. Replace the faulty Optical Transceiver', 'Action': '"Run the command 'replace transceiver' to replace the faulty Optical Transceiver.'}
- Step 3: {'Step': '3. Verify configuration of Optical Transceivers', 'Action': '"Run the command 'display optical transceiver configuration' to verify the configuration of Optical Transceivers.'}
- Step 4: {'Step': '4. Reboot the Access Switch', 'Action': '"Run the command 'restart system' to reboot the Access Switch.'}

## Post-Check Verification

```
display transceiver status
display optical link status
display optical transceiver information
```