

Huawei Access Switch Alarm Handling SOP

(ALARM_3666)

Node: Huawei-Access-Mumbai-MH-56 | **Vendor:** Huawei | **Severity:** Minor | **Alarm Code:** ALARM_3666

Description

This SOP outlines the steps to be taken when a Minor severity ALARM_3666 is raised on the Huawei Access Switch at Mumbai, Node ID: Huawei-Access-Mumbai-MH-56.

Potential Root Causes

Cause	Probability
Incorrect configuration of VLANs or VLAN mapping	Medium
Hardware issues with the switch or interfaces	Low
Software issues with the switch or firmware	High

Diagnostic Commands

```
display current-configuration | include vlan
display interface brief
display hardware-versions
display version
```

Resolution Steps

- Step 1: {'Step': '1. Check VLAN configuration and mapping', 'Action': "Run the command 'display current-configuration | include vlan' and verify if VLANs are correctly configured."}
- Step 2: {'Step': '2. Check interface status and statistics', 'Action': "Run the command 'display interface brief' and verify if any interfaces are down or have errors."}
- Step 3: {'Step': '3. Check switch and interface hardware versions', 'Action': "Run the command 'display hardware-versions' and verify if the hardware is compatible with the firmware."}
- Step 4: {'Step': '4. Check switch firmware version', 'Action': "Run the command 'display version' and verify if the firmware is up-to-date."}
- Step 5: {'Step': '5. Reboot the switch', 'Action': "Run the command 'reload' to reboot the switch."}
- Step 6: {'Step': '6. Verify the issue is resolved', 'Action': "Run the commands 'display interface brief' and 'display alarm' to verify if the issue is resolved."}

Post-Check Verification

```
display interface brief  
display alarm
```