

Huawei Access Switch Alarm SOP: ALARM_9660 (Major)

Node: Huawei-Access-Mumbai-MH-58 | **Vendor:** Huawei | **Severity:** Major | **Alarm Code:** ALARM_9660

Description

This SOP outlines the procedures to diagnose and resolve the ALARM_9660 (Major) alarm on Huawei Access Switch Node ID: Huawei-Access-Mumbai-MH-58.

Potential Root Causes

Cause	Probability
High CPU utilization or packet storm on the interface	High
Misconfigured VLAN or STP settings	Medium
Hardware failure on the interface or switch	Low

Diagnostic Commands

```
display interface brief
display cpu usage
display vlan information
display stp information
```

Resolution Steps

- Step 1: {'Step': 'Check CPU utilization', 'Action': 'Run the command: "display cpu usage" to check the CPU utilization on the switch.'}
- Step 2: {'Step': 'Verify VLAN and STP configurations', 'Action': 'Run the command: "display vlan information" and "display stp information" to verify the VLAN and STP configurations on the switch.'}
- Step 3: {'Step': 'Reset the interface', 'Action': 'Run the command: "reset interface [interface-name]" to reset the interface and clear the alarm.'}
- Step 4: {'Step': 'Replace hardware (if necessary)', 'Action': 'If the hardware failure is confirmed, replace the faulty hardware and verify the alarm is cleared.'}

Post-Check Verification

```
display interface brief
display cpu usage
```

```
display vlan information  
display stp information
```