

# Juniper Core Router SOP for Alarm Code

## ALARM\_7380

**Node:** Juniper-Core-Chennai-TN-1 | **Vendor:** Juniper | **Severity:** Minor | **Alarm Code:** ALARM\_7380

### Description

This SOP outlines the steps to diagnose and resolve the ALARM\_7380 minor alarm on the Juniper Core Router (Node ID: Juniper-Core-Chennai-TN-1).

### Potential Root Causes

| Cause                                            | Probability |
|--------------------------------------------------|-------------|
| Misconfigured routing protocol                   | Medium      |
| Interface issues (e.g., link down, MTU mismatch) | High        |
| Software or firmware issues                      | Low         |

### Diagnostic Commands

```
show routing-information
show interfaces | exclude "Protocol is Down"
show log messages | match ALARM_7380
show route | match
```

### Resolution Steps

- Step 1: {'Step': 'Verify routing protocol configuration', 'Action': 'Run "show routing-information" command and verify that protocol is configured correctly.'}
- Step 2: {'Step': 'Check interface status', 'Action': 'Run "show interfaces" command and verify that interface is up.'}
- Step 3: {'Step': 'Check MTU settings', 'Action': 'Run "show interfaces | exclude "Protocol is Down"' command and verify that MTU settings are consistent.'}
- Step 4: {'Step': 'Check log messages', 'Action': 'Run "show log messages | match ALARM\_7380" command and verify that there are no errors related to ALARM\_7380.'}
- Step 5: {'Step': 'Clear and re-advertise routes', 'Action': 'Run "clear routing-information" command and re-advertise routes using "set routing-information" command.'}

### Post-Check Verification

```
show routing-information
```

```
show interfaces | exclude "Protocol is Down"  
show log messages | match ALARM_7380
```