WORK INSTRUCTION

Document ID: DOC-0002671
Project: PRJ-008
Uploaded on: 2026-04-22
Uploaded by: user175
Export class: EAR99

Assembly of P-102726 at plant PLT03

Part Number: P-102726
Revision: A.1
Plant: PLT03
Station: ST-34
Torque (Nm): 12
Cycle time (s): 229

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Torque to specification

Step 4: Inspect incoming part

Step 5: Fit fasteners

Assembly of P-100399 at plant PLT04

Part Number: P-100399
Revision: B.1
Plant: PLT04
Station: ST-38
Torque (Nm): 5
Cycle time (s): 170

Step 1: Visual check

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Torque to specification

Step 5: Torque to specification

Step 6: Move to next station

Step 7: Fit fasteners

Step 8: Visual check

Assembly of P-103046 at plant PLT03

Part Number: P-103046
Revision: A.1
Plant: PLT03
Station: ST-74
Torque (Nm): 20
Cycle time (s): 127

Step 1: Inspect incoming part

Step 2: Apply thread locker

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Apply thread locker

Step 6: Record result

Step 7: Inspect incoming part