WORK INSTRUCTION

Document ID: DOC-0001582
Project: PRJ-017
Uploaded on: 2024-11-24
Uploaded by: user086
Export class: EAR99

Assembly of P-101681 at plant PLT01

Part Number: P-101681
Revision: A.1
Plant: PLT01
Station: ST-80
Torque (Nm): 2.5
Cycle time (s): 214

Step 1: Inspect incoming part

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Apply thread locker

Assembly of P-102132 at plant PLT04

Part Number: P-102132
Revision: A.1
Plant: PLT04
Station: ST-43
Torque (Nm): 12
Cycle time (s): 253

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Visual check

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Fit fasteners

Step 8: Torque to specification