WORK INSTRUCTION

Document ID: DOC-0001601
Project: PRJ-036
Uploaded on: 2024-12-03
Uploaded by: user036
Export class: EAR99

Assembly of P-102039 at plant PLT01

Part Number: P-102039
Revision: A.1
Plant: PLT01
Station: ST-12
Torque (Nm): 12
Cycle time (s): 119

Step 1: Inspect incoming part

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Inspect incoming part

Step 6: Inspect incoming part

Step 7: Move to next station

Assembly of P-101607 at plant PLT03

Part Number: P-101607
Revision: A.1
Plant: PLT03
Station: ST-71
Torque (Nm): 2.5
Cycle time (s): 238

Step 1: Torque to specification

Step 2: Torque to specification

Step 3: Visual check

Step 4: Record result

Step 5: Fit fasteners

Step 6: Visual check

Step 7: Move to next station

Assembly of P-101324 at plant PLT04

Part Number: P-101324
Revision: A.1
Plant: PLT04
Station: ST-93
Torque (Nm): 8

Cycle time (s): 228

Step 1: Clean mating surface

Step 2: Apply thread locker

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Inspect incoming part