WORK INSTRUCTION

Document ID: DOC-0001609
Project: PRJ-021
Uploaded on: 2024-12-08
Uploaded by: user148
Export class: EAR99

Assembly of P-100950 at plant PLT02

Part Number: P-100950
Revision: B.1
Plant: PLT02
Station: ST-50
Torque (Nm): 12
Cycle time (s): 99

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Clean mating surface

Assembly of P-100492 at plant PLT03

Part Number: P-100492
Revision: B.1
Plant: PLT03
Station: ST-75
Torque (Nm): 12
Cycle time (s): 271

Step 1: Apply thread locker

Step 2: Clean mating surface

Step 3: Record result

Step 4: Visual check

Step 5: Record result

Step 6: Clean mating surface

Step 7: Move to next station

Step 8: Torque to specification