WORK INSTRUCTION

Document ID: DOC-0001644
Project: PRJ-038
Uploaded on: 2024-12-27
Uploaded by: user128
Export class: EAR99

Assembly of P-100465 at plant PLT01

Part Number: P-100465
Revision: A.1
Plant: PLT01
Station: ST-48
Torque (Nm): 5
Cycle time (s): 57

Step 1: Fit fasteners

Step 2: Record result

Step 3: Record result

Step 4: Move to next station

Step 5: Move to next station

Step 6: Fit fasteners

Step 7: Fit fasteners

Assembly of P-100025 at plant PLT02

Part Number: P-100025
Revision: A.1
Plant: PLT02
Station: ST-50
Torque (Nm): 8
Cycle time (s): 289

Step 1: Apply thread locker

Step 2: Visual check

Step 3: Visual check

Step 4: Clean mating surface

Step 5: Clean mating surface

Step 6: Apply thread locker

Step 7: Record result

Assembly of P-100702 at plant PLT01

Part Number: P-100702
Revision: B.1
Plant: PLT01
Station: ST-23
Torque (Nm): 20

Cycle time (s): 150

Step 1: Move to next station

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Apply thread locker