WORK INSTRUCTION

Document ID: DOC-0002779
Project: PRJ-037
Uploaded on: 2026-06-20
Uploaded by: user058
Export class: EAR99

Assembly of P-101919 at plant PLT02

Part Number: P-101919
Revision: A.1
Plant: PLT02
Station: ST-32
Torque (Nm): 20
Cycle time (s): 205

Step 1: Apply thread locker

Step 2: Inspect incoming part

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Torque to specification

Step 6: Visual check

Step 7: Record result

Assembly of P-100118 at plant PLT02

Part Number: P-100118
Revision: B.1
Plant: PLT02
Station: ST-20
Torque (Nm): 12
Cycle time (s): 68

Step 1: Visual check

Step 2: Move to next station

Step 3: Record result

Step 4: Visual check

Step 5: Torque to specification