WORK INSTRUCTION

Document ID: DOC-0002780
Project: PRJ-030
Uploaded on: 2026-06-20
Uploaded by: user154
Export class: EAR99

Assembly of P-100084 at plant PLT02

Part Number: P-100084
Revision: C.1
Plant: PLT02
Station: ST-98
Torque (Nm): 12
Cycle time (s): 288

Step 1: Move to next station

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Inspect incoming part

Step 6: Apply thread locker

Assembly of P-103251 at plant PLT01

Part Number: P-103251
Revision: B.1
Plant: PLT01
Station: ST-38
Torque (Nm): 8
Cycle time (s): 275

Step 1: Fit fasteners

Step 2: Torque to specification

Step 3: Torque to specification

Step 4: Record result

Step 5: Torque to specification

Assembly of P-100216 at plant PLT03

Part Number: P-100216
Revision: E.1
Plant: PLT03
Station: ST-39
Torque (Nm): 2.5
Cycle time (s): 202

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Torque to specification

Step 5: Inspect incoming part